

Formulation Example

MDA-P-185-01 SK 03 Pore Prep Potion UNPOREABLE

Ingredients	Art. No.	INCI EU	[%]
A			
RonaCare® Nicotinamide	1.30179 (1)	NIACINAMIDE	3.00
RonaCare® Ectoin	1.30200 (1)	ECTOIN	0.50
Sodium Gluconate	(2)	SODIUM GLUCONATE	0.10
Dermosoft® 1388 eco	(3)	GLYCERIN, AQUA, SODIUM LEVULINATE, SODIUM ANISATE	3.00
Water, demineralized		AQUA	68.60
B			
Glycerol anhydrous (vegetable) EMPROVE® bio	1.37028 (1)	GLYCERIN	3.00
Kelco-Care™ diutan gum	(4)	SPHINGOMONAS FERMENT EXTRACT	0.30
VIVAPUR® CS 032 XV	(5)	MICROCRYSTALLINE CELLULOSE, XANTHAN	0.50
C			
RonaCare® Bisabolol nat.	1.30170 (1)	BISABOOL	1.00
Imwitor® 375	(6)	GLYCERYL CITRATE/LACTATE/LINOLEATE/OLEATE	4.00
Lanol™ 37 T	(7)	TRIHEPTANOIN	4.00
Miglyol® Coco 810	(6)	COCO-CAPRYLATE/CAPRATE	5.00
Tegosoft® OER	(3)	OLEYL ERUCATE	3.00
RonaFlair® LDP White	1.17755 (1)	SODIUM POTASSIUM ALUMINUM SILICATE, CI 77891, SILICA	3.00
Citric acid, 30% solution (q.s.)		AQUA, CITRIC ACID	0.00

Procedure:

Cold-Process:

Prepare phase A. Mix phase B in a separate vessel, and add phase B to phase A.

Homogenize with U-Turrax (T-25 8000 rpm) for 5 min. Add ingredients of phase C one after the other into phase A/B, add, adjust pH to 5,0 and homogenize with U-Turrax (T-25 8000 rpm) for 1 min.

Notes:

Appearance: off white - light beige serum (O/W)

pH value: 5,0 (23°C)

Viscosity: 6500-7000 mPas (Brookfield DV-I, spindle RV 4, 10 rpm, Helipath) at 23°C

Stability: 3 months at RT, 40°C, 5°C, FTC (-5°C to 40°C) and 1 week at 50°C

NOC (ISO 16128) = 96,9

Suppliers:

(1) Merck Electronics KGaA / EMD Performance Materials Corp.

(3) Evonik Nutrition & Care GmbH

(5) J. Rettenmaier & Söhne GmbH

(7) Seppic

(2) Jungbunzlauer GmbH

(4) RAHN GmbH

(6) IOI Oleo GmbH

Formulation Example

Products are warranted to meet the specifications set forth on their label/packaging and/or certificate of analysis at the time of shipment or for the expressly stated duration. Merck Electronics KGaA ("Merck") provides information and advice on application technologies and relevant regulations based upon its current knowledge and opinion. MERCK MAKES NO REPRESENTATION OR WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE REGARDING OUR PRODUCTS, THEIR APPLICATION OR ANY INFORMATION PROVIDED IN CONNECTION THEREWITH. Merck shall not in any event be liable for incidental, consequential, indirect, exemplary or special damages of any kind resulting from any use or failure of the products. Customer is responsible for and must independently determine the suitability of Merck's products for its products, intended use and processes. The foregoing information and suggestions are also provided without warranty of non-infringement as to intellectual property rights of third parties and shall not be construed as any inducement to infringe the rights of third parties. Customer shall be responsible for obtaining any applicable third party intellectual property licenses. All sales are subject to Merck's complete Terms and Conditions of Sale. Prices are subject to change without notice. Merck reserves the right to discontinue products without prior notice. □

© 2023 Merck KGaA, Darmstadt, Germany and/or its affiliates. Merck, the vibrant M, Colorona, Timiron, Xirona, RonaFlair, Ronastar, Ronaflux, Candurin, Eusolex, Parteck, Oxyxex, RonaCare, IR3535, UV-Pearls, ASCIII, Luremin and Emblica are trademarks of Merck KGaA, Darmstadt, Germany or its affiliates. All other trademarks are the property of their respective owners. Detailed information on trademarks is available via publicly accessible resources.