

FORMULATION example

MDA-S-201-12 SK05 SunSilk Soft Cream with SPF 30, UVA

Ingredients	Art. No.	INCI EU	[%]
A1			
Eusolex® T-PURE	1.05947 (1)	TITANIUM DIOXIDE (NANO), ALUMINA, SILICA	5.00
A2			
Eusolex® OS	1.06949 (1)	ETHYLHEXYL SALICYLATE	5.00
Oxyhex® ST Liquid	1.30217 (1)	DIETHYLHEXYL SYRINGYLIDENEMALONATE, CAPRYLIC/CAPRIC TRIGLYCERIDE	0.50
Cetiol® B	(2)	DIBUTYL ADIPATE	12.00
Cetiol® OE	(2)	DICAPRYLYL ETHER	6.00
Tegosoft® TN	(3)	C12-15 ALKYL BENZOATE	6.00
Dispersun DSP-OL100	(4)	POLYHYDROXYSTEARIC ACID	0.73
A3			
DHHB		DIETHYLAMINO HYDROXYBENZOYL HEXYL BENZOATE	3.00
Eusolex® BEMT	1.32992 (1)	BIS-ETHYLHEXYLOXYPHENOL METHOXYPHENYL TRIAZINE	2.50
Eusolex® EHT	1.32994 (1)	ETHYLHEXYL TRIAZONE	1.50
Nafol 1618H	(5)	CETEARYL ALCOHOL	2.00
B1			
Glycerol anhydrous (vegetable) EMPROVE® bio	1.37028 (1)	GLYCERIN	3.00
Complexing agent			q.s.
Water, demineralized		AQUA	ad 100
B2			
VIVAPUR® CS TEX SUN	(6)	MICROCRYSTALLINE CELLULOSE, CELLULOSE GUM	0.30
Solagum™ AX	(7)	XANTHAN GUM, ACACIA SENEGAL GUM	0.30
B3			
Amphisol® K	(8)	POTASSIUM CETYL PHOSPHATE	3.00
C			
RonaFlair® LDP White	1.17755 (1)	SODIUM POTASSIUM ALUMINUM SILICATE, CI 77891, SILICA	3.00
Preservatives			q.s.
Fragrance		PARFUM	q.s.

Procedure:

Disperse Phase A1 into phase A2 (Dissolver disc). Add phase A3 to phase A1/2. Disperse phase B2 in phase B1. Add phase B3 to phase B1/2. Heat phase A and phase B to 75-80 °C. Add phase A to phase B while stirring. Homogenize. Cool down while stirring. Add phase C at 40 °C.

Notes:

Appearance: off-white o/w soft cream

pH value: 6.5 (23 °C)

Viscosity: 20.000 mPa.s (Brookfield DV-II+, Helipath spindle C,10 rpm) at 23 °C

Stability: 1 months at 40 °C, FTC (-5 °C to +40 °C), 5 °C, RT and 1 week at 50 °C

Suppliers:

(1) Merck KGaA, Darmstadt, Germany / EMD Performance Materials Corp.

(3) Evonik Nutrition & Care GmbH

(5) Sasol Germany GmbH

(2) BASF AG

(4) Innospec

(6) J. Rettenmaier & Söhne GmbH

FORMulation example

(7) Seppic

(8) DSM Nutritional Products GmbH

Products are warranted to meet the specifications set forth on their label/packaging and/or certificate of analysis at the time of shipment or for the expressly stated duration. Merck Electronics KGaA ("Merck") provides information and advice on application technologies and relevant regulations based upon its current knowledge and opinion. MERCK MAKES NO REPRESENTATION OR WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE REGARDING OUR PRODUCTS, THEIR APPLICATION OR ANY INFORMATION PROVIDED IN CONNECTION THEREWITH. Merck shall not in any event be liable for incidental, consequential, indirect, exemplary or special damages of any kind resulting from any use or failure of the products. Customer is responsible for and must independently determine the suitability of Merck's products for its products, intended use and processes. The foregoing information and suggestions are also provided without warranty of non-infringement as to intellectual property rights of third parties and shall not be construed as any inducement to infringe the rights of third parties. Customer shall be responsible for obtaining any applicable third party intellectual property licenses. All sales are subject to Merck's complete Terms and Conditions of Sale. Prices are subject to change without notice. Merck reserves the right to discontinue products without prior notice. □

© 2023 Merck KGaA, Darmstadt, Germany and/or its affiliates. Merck, the vibrant M, Colorona, Timiron, Xirona, RonaFlair, Ronastar, Ronaflux, Candurin, Eusolex, Parteck, Oxyxex, RonaCare, IR3535, UV-Pearls, ASCIII, Luremin and Emblica are trademarks of Merck KGaA, Darmstadt, Germany or its affiliates. All other trademarks are the property of their respective owners. Detailed information on trademarks is available via publicly accessible resources.